PLATINUM

SERIES

PLW-15

Set Up Guide

1 Key

= Auto Timer

AV = Audio Visual

= Caution

EQ = Equaliser Graphic Interface

= Factory Default Setting

= For Advanced Operations only

LFE = Low Frequency Enhancement

= PLW-15 Manual Page Reference

= No

Inp = Stereo

= User Setting

= Volume

= Volume Adjustment

= Yes

= 12v Trigger

Please read all the safety information in the manual before proceeding to connect and power up your PLW-15

2 Connecting your PLW-15

Using a Stereo / 2 Channel Amplifier
Refer to page 5

Rear panel view



Recommend connection
12v DC trigger (if available)

Using the AV/ Receiver LFE out
Refer to page 3

7

3 Rear Panel View

3a



POWER

ON OFF

3b

7

PLW15 Setup Guide.indd 2 30/04/2008 11:30:01

4



5 Initial Setup -
Using the 4 Factory Pre-Sets

- MOVIES
- MUSIC
- IMPACT
- DYNAMIC

} Factory pre-set EQ settings

Refer to your AV Amplifier/Receiver manual to set up the appropriate crossover settings on your AV/Receiver

9

6 Remote Control Handset
and Control Panel

EQ FACTORY SETTINGS

MUTE	x 1 = ON x 2 = OFF
LFE	x 1 = Inp (STEREO) x 2 = LFE (AV)
MOVIES	x 1 = Movi x 2 = USER
MUSIC	x 1 = Musi x 2 = USER
IMPACT	x 1 = Impa x 2 = USER
DYNAMIC	x 1 = Dyna x 2 = USER
NIGHT MODE	x 1 = Nigh ON x 2 = Nigh OFF
STAND BY	x 1 = OFF (STAND BY) x 2 = ON (POWER UP)
EXIT	

Movies
Music
Impact
Dynamic
User

} EQ Setting

Level Setting

LFE / Input

Graphic Output Level

For Basic Operations



OR



7-8

PLW15 Setup Guide.indd 3 30/04/2008 11:30:03

Advanced Set-up for LFE Input Connection Functions & Operations Overview



1.

2.

3.

All screens will time out in 10 seconds. No settings will be lost UNLESS the PLW-15 is powered off or put into stand-by mode.

4.



5.



5a.



5b.



PLW15 Setup Guide.indd 4 30/04/2008 11:30:06















PLW15 Setup Guide.indd 5 30/04/2008 11:30:12

Advanced Set-up for Stereo/ 2 Channel Input Connection

Functions & Operations Overview



1.

2.



All screens will time out in 7 seconds. No settings will be lost UNLESS the PLW-15 is powered off or put into stand-by mode.

3.



4.



4.

PLW15 Setup Guide.indd 6 30/04/2008 11:30:14

Please refer to step 5. of the
LFE Advanced Set-Up (page 3) to
continue to the next stages of
setting up your PLW-15.

PLW15 Setup Guide.indd 7 30/04/2008 11:30:14

Monitor Audio Ltd
Unit 2, 24 Brook Road
Rayleigh, Essex
SS6 7XL
England
Tel: 01268 740580
Fax: 01268 740589
Email: info@monitoraudio.co.uk

www.monitoraudio.co.uk

Designed in the United Kingdom

Version 1